

Installation Instructions >> Pannier Racks >> KTM Adventure



Installation Instructions >> Pannier Racks >> KTM Adventure

1. Remove the factory pannier mounts using a T45 torx key.

2. Mount the left side pannier and secure on the top using one of the M8x30mm bolts. Leave it loose.



3. Hand-thread another M8x30mm bolt to partially secure the left side pannier before you move onto the next step.



4. Make sure that the pannier rack is loose enough to fit the spacers behind the mounting tab.



Installation Instructions >> Pannier Racks >> KTM Adventure

5. Longer bolt will go on top and shorter (M8x45mm) on the bottom. Don't forget to add the washers.



6. Insert and han-thread both bolts. Leave it loose!



7. Optional step to gently tighten the upper bolts, in case you're having a hard time hand-threading them.



8. Using an 8x40mm Allen bolt, washer and locking nut tie the top left side of the pannier rack into the pre-mounted bracket. Leave it loose.



Installation Instructions >> Pannier Racks >> Africa Twin 1000

9. Move onto mounting the right side pannier rack.



10. Repeat step #4, #5 and #6 on the right side. This time you'll use the M8x30mm bolts.



11. Mount the rear cross brace.



12. Using the all four M6x20mm hex bolts, locking nuts and washers, secure the rear cross brace. Recommend tools: 10mm wrench and 10mm socket and ratchet but another option is two 10mm wrenches.

Finally tighten ALL the bolts and nuts!



Installation Instructions >> Pannier Racks >> KTM Adventure

Hardware List and Recommended Tools



1. 6mm Allen key or 6mm Allen socket
2. 10mm wrench
3. Optional 2nd 10mm wrench
4. 10mm hex socket
5. Ratchet extension
6. Ratchet

7. 1x M8x55mm Allen bolt
8. 1x M8x45mm Allen bolt
9. 6x M8x30mm Allen bolt
10. 4x M6x 20mm hex bolt
11. 4x spacers
12. 4x M6 locking nuts
13. 4x M6 washers
14. 8x M8 washers