

Phone 03 5729 5556 Fax 03 5729 5559

1933 Carboor Everton Rd, Carboor, Victoria, Australia, 3678

YAMAHA 2019 Tenere 700 25L

IMPORTANT!

Pre-fitting Instructions for Safari Fuel Tanks

- 1. These instructions assume that the installer is familiar with removing and installing the OEM fuel tank that comes standard with this motorcycle. These instructions will highlight the unique steps to install the Safari tank. Please read the complete instruction before starting to install the fuel tank.
- 2. Rinse tank out with a small amount of petrol and then discard the petrol. This needs to be done to remove any plastic trimmings that may be left in the tank after manufacturing.
- 3. Before attaching the screws and bolts to the brass inserts, ensure that an anti-seize compound grease will do is applied to the threads. **Do not use thread retaining compounds.** If there is a risk of the screws and bolts working loose, use lock wire to secure them mainly for endurance competition events.



Parts List

- □ 1 X EFI Pump Retainer Plate
- □ 6 X M5 x 16mm But Soc Screw
- □ 2 x Plastic Plug

FITTING INSTRUCTIONS

- 1. Remove the seat and OEM fuel tank.
- 2. Remove the front and rear brackets from the OEM fuel tank.





3. Remove the EFI fuel pump from the OEM tank and install into the Safari tank using the fuel pump retainer and screws supplied with the Safari tank. Orientate the fuel pump outlet towards the rear (same as OEM tank in the below picture) to allow the fuel line to be connected once the tank is installed on the motorcycle.





4. Install the front bracket onto the Safari tank.





5. Plug the disconnected fuel overflow line (as this is not used with the Safari tank)



6. Install the Safari tank onto the motorcycle by angling the tank from the righthand side of the motorcycle and raising the back of the tank to allow it to fit pass the posts on the plastic fairing tower.



7. Check that the tank is in the correct location on the front rubber mounting.



8. Complete the installation by attaching the rear bracket of the tank to the motorcycle frame.

9. Refit the radiator/side covers by clipping into the cavity on the Safari fuel tank. Note: the top screw on the side panel is not used with the Safari fuel tank and can be plugged with the plastic plug supplied (the plug will need to be cut to the required length so it does not restrict installation of the side covers).



10. Refit the seat.

Check that all fittings and hoses are secure and then put a small amount of fuel in the tank and CHECK THE ENTIRE SYSTEM FOR LEAKS.